Traffic Data Collection for Tactical Advantage

LaserSoft® SpeedStat software

All you need:

- A compatible LTI speed enforcement laser
- Any Windows PC running 7+
- LaserSoft® SpeedStat software





Quick Set Up

- Connect a laser to a PC via cable or Bluetooth*
- Launch SpeedStat& Click [Collect]
- Verify COM port & serial data
- Enter file details & start clocking cars












Calculations Summary


- Set a Date and Time Filter
- Set a Speed Filter
- Review Quick Stats for: Vehicles, Speed Limit, Lowest Speed, Highest Speed, Average Speed, and Pace Speed.
- Percentiles





Graphs


- Normal Distribution conventional bar graph of measured speeds
- Cumulative Distribution The percentage of vehicles in increasing speed ranges
- Direction Filter Filter by direction of traffic for approaching or departing vehicles



Reports

- Spreadsheet Report
- Text Report
- ▶ **Intervals:** 15, 30, & 60 minutes.

>>>>>





Compatible Laser Models

- TruVISION™ (6-pin cable)
- TruCAM™ II (6-pin cable)
- UltraLyte® (4-pin cable)
- TruSpeed® LR (4-pin cable)
- TruSpeed® Sxb (4-pin cable) *Bluetooth
- > TruSpeed® Se (4-pin cable or Bluetooth)



















